

SUBARU V13.0

Table of Contents

1	Vehicle systems covered	1
2	Vehicle Special Function covered	1

1 Vehicle systems covered

System	DTC	Data List	Active Test	Special Func
Engine	X	X		X
AT	X	X		X
ABS	X	X		X
EPS	X	X		
SRS	X	X		
TPMS	X	X		X
IUM	X	X	X	X
ASS	X			X
ACS	X	X	X	X
CCS	X	X		
Impact Sensor	X	X		X
Automatic Light and Wiper	X	X	X	X
Keyless access system	X	X		X
CAN System	X			
Occupant Detection System	X			X
Brake Vacuum Pump System	X	X		X

2 Vehicle Special Function covered

System	Special Function
Engine	Dealer Check Mode Procedure
Engine	System Operation Check Mode
Engine	Diagnosis Results
Engine	Cancel Code(s) Display
Engine	DPF maintenance
Engine	Oil maintenance mode
Engine	Maintenance at the time of ECM replacement
Engine	Injector or Engine Replacement
Engine	ECM Replacement
Engine	Injector Code Display
Engine	Fuel pump duty learning
Engine	Fuel injector injection amount learning
Engine	EGR valve opening angle learning
AT	Function Check Sequence
AT	Dealer Check Mode Procedure

System	Special Function
AT	AT learning mode
AT	Oil inspection mode
AT	Rear differential inspection mode
AT	AWD ON/OFF switching mode
AT	Clear Memories 2
ABS	Freeze Frame
ABS	Function Check Sequence
TPMS	Transmitter ID regist confirm
IUM	ECUCustomize
IUM	Fun_checkmenu
IUM	Keyless ID Regist
ASS	CompulsoryHeightControl
ACS	Variable compressor break-in drive
ACS	Freeze Frame
Impact Sensor	SensitivityAdjustmentMode
Automatic Light and Wiper	Sensor initial setting
Keyless access system	Collation ECM output check
Keyless access system	Keyless access system check
Keyless access system	Power supply ECU output check
Keyless access system	Keyless ID Regist.
Occupant Detection System	Re-zeroing
Brake Vacuum Pump System	Function Check Sequence
	Maintenance Reset